

POINTS TO REMEMBER

- Check your credit on a regular basis by pressing red button 'A'.
- To transfer credit you don't need to press any buttons. Insert your PAYEASY card into the slot/gold chip first, with blue arrow showing as in fig.1 for about 5 seconds until you hear a beep.
- When your screen display is updating you will see a flashing box, or 'Please wait'
- The red button 'A' is used to release your 'Credit reserve'. The black button 'B' is only used to switch the gas supply back on
- The word 'Lo' flashing or 'Reverse avail' means you can release your 'Credit Reserve' before your gas supply switches off at 15 units. (See previous page)
- A flashing 'c' or 'OFF' means your gas suppy has switched off. Don't worry, all you have to do is access your 'Credit Reserve' (see previous page).
- 'O' with 'rES' flashing or 'ON' with 'Reverse in use' means you are using your Credit Reserve. Purchase more credit as soon as possible.
- If you leave your card in the meter for more than a minute, you will need to remove it and re-insert it before attempting any of the previous instructions.
- If you smell gas or are are concerned about safety call 0800 002 001.

PHOENIX NATURAL GAS SUPPLY

197 Airport Road West, Belfast, BT3 9ED Telephone 0845 900 5253 Minicom 028 9055 5801 E-mail: info@phoenixsupplyni.com Internet: www.phoenixsupplyni.com

The above instructions are from Phoenix Gas for the operation of their pay as you go card meters.

The majority of our properties would be supplied with phoenix gas and use the PAYEASY card system.

You should always keep your meter above 15 units so that it does not shut off unexpectedly.

If this happens the boiler may require resetting.

Please ensure you have sufficient credit on your gas meter before reporting a problem with your heating to us. It may be that you just have run out of credit.